



Professional single zone electronic timer



Battery Installation

Install 2 AA Alkaline batteries by removing the battery holder from the back of the timer and inserting the batteries. Replace the battery holder.

Please install fresh batteries if the battery status indicates below on the LCD display.

Please recycle batteries after use.

Please do not use rechargeable battery.

Programming

Please note for ease of programming, this unit is best to be set up prior to connecting to your tap.

1. Set Current Time

Press ◀ or ▶ button to decrease / increase time to the current time.

Press ▼ or (OK) button to confirm to next step.

2. Set Water Start Time

Press ◀ or ▶ button to decrease / increase time to the desired watering start time.

Press ▼ or (OK) button to confirm to next step.

3. Set How Long

Press ◀ or ▶ to decrease / increase the duration (up to 240 minutes).

Press ▼ or (OK) button to confirm to next step.

4. Set Water Frequency

A. There are 11 water frequencies selections available.

B. They are every 4HRS, 6HRS, 8HRS, 12HRS, 1 DAY, 2 DAY, 3 DAY, 4 DAY, 5 DAY, 6 DAY and 7 DAY

C. Use ◀ or ▶ to select desired watering frequency.

D. Press ▼ or (OK) button or wait for 3 seconds to confirm to next step.

Activate Programming

1. Press ◀ or ▶ button to move the indicator to "ON".

2. Press ▼ or (OK) button to confirm "ON" to activate the program.

Disabling the Program

In the case of suspending automatic watering for an extended period, scroll down to Programme and

Press ◀ or ▶ button to move the indicator from "ON" to "OFF".

Press (OK) button to confirm "OFF" to disable the program.

Note if you need to turn the programme on again, follow the last steps and select "ON" and press (OK) the original programme you set up will be remembered and will resume on the next cycle.

Manual Watering

Hand watering override setting

During non programmed times where you need water supply, simply scroll to manual and press ▶ for every minute you need to hand water then press (OK).

This will open the valve and supply water until the time has lapsed. or if you prefer,

turn the tap off and unscrew the timer from the tap to use the tap until you are finished and re-attach to tap.

*At any time, you can turn to off or add time, then when finished turn off to resume programme

Installation

Attach timer to faucet and hose. Open the faucet and leave it open. Water will come on and shut-off at the selected time.

Care and Maintenance

1. For outdoor use only.

2. Operating water pressure: under 10~100 PSI (0.7~7 bar).

3. Operating water temperature: 32°F (0°C) ~ 100°F (38°C).

A. Turn off the faucet and remove the timer from the faucet.

B. Manual on the timer to open the valve to drain out water.

C. Remove the batteries.

D. Dry the timer and store the timer in a dry place.



**FROST
WARNING**

NOT SUITABLE
IN FREEZING
CONDITIONS